

Installation Instructions Eco Hand Dryer



1. Fix the mounting plate:

- Having removed the mounting plate from the rear of the dryer, fix to the wall using the provided fixings as per the diagram measurement guide.

2. Hang the dryer on mounting plate:

- Carefully hang the dryer chassis on to the mounting plate and ensure it is securely attached.

3. Secure using provided screws

- Insert the provided screws to affix the dryer firmly to the mounting plate.

Recommended Mounting Heights

Measurements are from the base of the unit to the floor

- Mens: 45" (114 cm)
- Ladies: 43" (109 cm)
- Teenagers: 41" (104 cm)
- Small Children: 35" (89 cm)
- Disabled: 39" (99 cm)

